



T Trevi-3 ht45 d50 epa83 HP88



T Trevi-3 ht45 50tr epa83 MET

EPOXY (ep../epa..) - Ø 25,4 - HT40/45

Trevi-3 HPL / MHA / HM / MET / HA00

		d50	50tr	70	90
L x B		Ø50	50 tri	Ø70	Ø90
H (hpl)	HT40	40,0	40,0	40,6	40,8
	HT45	45,0	45,0	45,6	45,8
BD (mm)	HPL/MHA/HM	18 mm	18 mm	24 mm	26 mm
	HA00	18 mm	18 mm	-	-
	MET	-	2,5 mm	-	-
PH	HT40	38,2	38,2	38,2	38,2
	HT45	43,2	43,2	43,2	43,2
PB		-	-	-	-
PL		-	-	-	-
[m³] (ht40)		0,03	0,03	0,06	0,07
[kg] (ht40)	HPL/MHA/HM	5,0-6,0	4,6-5,6	8,8-10,2	13,7-15,7
	HA00			-	-
	MET	-	5,6-6,6	-	-



T Trevi-4 HT45 90C epa15 HP98




Ens. T Trevi-4 ht40 70C & T Trevi-4 ht45 90C & T Cup ht55 5033C MET


EPOXY (ep../epa..) - Ø 25,4 - HT40/45

Trevi-4 HPL / HA / HM

		70C	90C	100	110	120
L x B		circ. 70x70	circ. 90x90	Ø100	Ø110	Ø120
H (hpl)	HT40	40,0	40,8	40,8	40,8	40,8
	HT45	45,0	45,8	45,8	45,8	45,8
BD (mm)	HPL/HA	18 mm	26 mm	26 mm	26 mm	26 mm
	HM	18 mm	-	18 mm	-	-
PH	HT40	38,2	38,2	38,2	38,2	38,2
	HT45	43,2	43,2	43,2	43,2	43,2
PB		-	-	-	-	-
PL		-	-	-	-	-
[m³] (ht40)		0,06	0,08	0,10	0,11	0,14
[kg] (ht40)	HPL/HA	8,7-10,1	16,6-18,6	17,9-20,4	20,7-23,5	23,5-26,6
	HM	8,7-10,1	-	17,9-20,4	-	-



Tafels



- **D** = Diepte
- **H** = Hoogte
- **L** = Lengte
- **BD** = Bladdikte
- **PB** = Ruimte tussen de poten aan de korte zijde
- **PH** =

Ruimte onder het kader (= vrije ruimte voor armleuning van stoel)

- **PL** = Ruimte tussen de poten aan de lange zijde

